ClassMate[™]

ROBOTIC WELDING TRAINER



ADVANCING THE MANUFACTURING SKILLS OF THE NEXT GENERATION

As businesses of all sizes now compete on a global stage, manufacturing companies are challenged to increase productivity, improve quality and reduce costs.

These challenges, coupled with the critical skilled labor shortage, drive many manufacturers to implement automated welding fabrication. Employers everywhere are demanding that prospective employees be trained in robotic fabrication technologies. Educators are rapidly moving to respond.

The Lincoln Electric ClassMate[™] Robotic Trainer provides the education community with a complete advanced manufacturing solution for robotic welding training.

Product Number »

AD2446-1 Basic Package

AD2446-2 Intermediate Package

AD2446-3 Advanced Package



FEATURES — All Models

- » Includes everything you need to present robotic manufacturing
- » Classroom Ready Use the robot and controller for robot operation and programming in the classroom using supplied 120VAC input power cable (welding operation requires greater input voltage)
- » Exclusive use of Fanuc® robots number one most popular robot manufacturer in the U.S.
- » New, larger expandable work surface and enclosure easily sets up in seconds.
- » Full-featured, operational robotic welding power source
- » Integrated fume control
- » Fits through a standard doorway to teach and practice programming in a classroom and move to the lab to practice welding
- » Integrated safety measures in system and software
- » 3 Basic Robotic Programming class seats

APPLY THE CLASSMATE INTO MULTIPLE PROGRAMS

- » Industrial. Mechanical and Advanced Manufacturing Welding
- » Engineering or Technology
- Production Processes
- » Lean Manufacturing and Manufacturing Management
- » 3D / CAD / Virtual Prototyping Programming Classes
- » Manufacturing Operations, Mechatronics, Quality Control and Inspection

The Lincoln Electric Robotic ClassMate Cell is a complete robotic training solution designed to meet the need for advanced manufacturing training. Instructors can teach robotic concepts in the classroom and quickly move to the lab for welding practice. Students can perform offline programming and then test their skills at a manufacturing-ready robotic cell.

BENEFITS OF ROBOTIC WELDING TRAINING:

Provide students with advanced manufacturing skills.

Increase student participation and engagement with a hands-on training solution.

Teach robotics using the equipment implemented in manufacturing and fabrication facilities.

Accelerate student skills and capabilities for high graduation employment rates.

Pique interest and enrollment with this exciting recruitment tool.

THE LINCOLN ELECTRIC ROBOTIC WELDING EDUCATION CELL IS IDEAL FOR:

- · Training and demonstration purposes in a welding lab, classroom or even at a recruitment event
- · Technical training at universities
- Trade schools
- · Workforce development programs

Purchase includes access to the Lincoln Electric Train-the-Trainer Program, including curriculum and safety materials. Our goal is to help instructors and students develop the skills necessary to thrive in an advanced manufacturing environment.



Miniflex® with EN 20 Extraction Nozzle, Welding Fixture, and Project Based Lessons

PACKAGES - WHAT'S INCLUDED			
	PACKAGE1- Basic (AD2446-1)	PACKAGE 2 - Intermediate (AD2446-2)	PACKAGE 3 - Advanced (AD2446-3)
Robotic 3-in-1 Welding Fixture — The patent pending 3-in-1 adjustable welding fixture is designed for use on a robotic weld training system. It enables the welding instructor to teach common industry-standard joints and positions, all in one simple device.	•	•	•
Miniflex® Welding Fume Extractor — A portable, effective high vacuum system for the removal and filtration of welding fumes in confined and other hard to reach spaces. Integrates into bracket on cell.	•	•	•
EN 20 Extraction Nozzle — Funnel extraction nozzle stand offers positioning flexibility.	•	•	•
Custom Lettering Program — Preprogrammed with easy to use high quality lettering.	•	•	•
Robotic Welding Project Based Lesson (K3976-2) — Offer instructors more than a dozen complete project curriculum designed to encourage active inquiry, higher level thinking and easy integration into advanced manufacturing education programs. Includes learning activities, step-by-step instructions and discussion questions.	•	•	•
Basic Robotic Programming Class 3-5 Days for up to 3 instructors	•	•	•
Standard 120VAC input power connection	•	•	•
WeldPRO Training Program and Software		•	•
IRVision 2D vision camera system			•
Additional WeldPRO Instructor Seat		•	•

Optional
 Included

WeldPRO Training Program

(Included with Intermediate and Advanced Packages. Can also be purchased separately)

Train-the-Trainer program is designed to train instructors to enable their own training of students to program FANUC robots.

Training Program and Software Package includes:

- » Instructor License (1 Seat)
 - WeldPRO Simulation Software (laptop not included)
 - Starts at time of registration
 - Permanent Does not expire
- » Instructor Basic Robotic Training at Lincoln Electric (3 Seats)
- » Student WeldPRO Simulation Software License Package¹
 - 12 month subscription per student (laptop not included)
 - Student Licenses (25 Seats)
 - Can be renewed annually
 - School has 90 days to register student licenses before
 month student subscriptions start

Additional Instructor Seat Option (AD1034-50)

» Add one additional instructor License (1 seat) for the WeldPRO Training Program and Software Package

Annual Renewal for Student Licenses Option (AD1034-55)

- » 12 month subscription per student (laptop not included)
- » Student Licenses (25 Seats)
- » Can be renewed annually
- School has 90 days to register student licenses before
 month student subscriptions start

Robotic System Specifications

Product Number	AD2446-1 Basic AD2446-2 Intermediate AD2446-3 Advanced
Weight – lb (kg)	1000 lb.
HxWxD – in (mm)	81.23 x 64.82 x 70 (sides expanded); 32 in. (sides folded)
Input Voltage	120V for Robot operation and programming

Power Wave® S350 and AutoDrive® 4R100 Product Specifications

Product Number	Power Wave S350: K2823-3 AutoDrive 4R100: K3002-2
Output Range	5-350A
Rated Output – Current/Voltage/ Duty Cycle	GMAW: 350A/31.5V/40% GMAW: 300A/29V/100%
Input Voltage	208/230/380-415/460/575VAC single or 3 Phase 50 or 60 Hz

Robot Specifications

RooteSpecifications	
FANUC ARC Mate® 50iD/7L	Six Axis Mechanical Unit To kg Maximum Payload Oughton
FANUC R-30iB Mate Controller	6-channel servo amplifier RIA compliant E-stop unit Integrated operator panel (includes Auto/T1 mode switch, Estop and cycle start push buttons) RIA-compliant color haptic iPendant with non touch panel and USB2.0 port
FANUC Robotics LR ArcTool® Software	Compliant with RIA R15.06 Safety Requirements

Safety/Weld Cell Controls

- CSA/UL certification ready system PLEASE NOTE: Obtaining CSA/UL certification is the responsibility of the customer
- Fully integrated ANSI/RIA 15.06-2012 compliant operator safety devices including door safety switches
- · RIA compliant robotic controller operator panel, robotic software and pendant

Complete System Documentation

Hard Copy binder	
Electronic manuals and tools	operations manuals maintenance guides, spare parts lists, calibration numbers and serial numbers, print, and supplier references and specifications

Training Classes

Basic Robotic Programming Class

- · 3-5 days (depending on options selected
- · 3 instructor seats
- · Learn how to program and operate the cell
- · Access to Lincoln Electric welding and robotic team

WeldPRO

· See page 3 for details

JOIN THE LINCOLN ELECTRIC EDUCATION COMMUNITY!

Sign up for the First Pass™ Newsletter at www.lincolnelectric.com/firstpass:

See upcoming events, customer highlights, Lincoln Electric activity, updates and tips and tricks to help with your implementation of welding training in your environment.

twitter.com/LincolnElectric

Interact with us on Twitter* and let us know how, where and when you are using your welding training products.

facebook.com/LincolnElectric

Join us online and hear what others are saying. Interact and like posts and updates that you find exciting and interesting. We'd be happy to hear from you.

EXCEPTIONAL CUSTOMER SERVICE

Lincoln Electric has a global network of facilities and people to provide quick response and personalized attention. No matter where your welding operations are located today, no matter where they will be tomorrow, Lincoln Electric experts are ready to provide local support and create and implement solutions to fit your needs.

SERVICE AND SUPPORT THAT YOU CAN COUNT ON

- » 24/7 Phone Support 1-888-935-3878
- » Contact us with comments or questions automation@lincolnelectric.com
- » Education resources: www.lincolnelectric.com/education
- » Warranty and Service Support
- » Train-the-Trainer programs held regularly in facilities or on-site training and set-up can be purchased.

CUSTOMER ASSISTANCE POLICY

The business of The Lincoln Electric Company* is manufacturing and selling high quality welding equipment, consumables, and cutting equipment. Our challenge is to meet the needs of our customers and to exceed their expectations. On occasion, purchasers may ask Lincoln Electric for information or advice about their use of our products. Our employees respond to inquiries to the best of their ability based on information provided to them by the customers and the knowledge they may have concerning the application. Our employees, however, are not in a position to verify the information provided or to evaluate the engineering requirements for the particular weldment. Accordingly, Lincoln Electric does not warrant or guarantee or assume any liability with respect to such information or advice. Moreover, the provision of such information or advice does not create, expand, or alter any warranty on our products. Any express or implied warranty that might arise from the information or advice, including any implied warranty that might arise from the information or advice, including any implied warranty of specifically disclaimed.

Lincoln Electric is a responsive manufacturer, but the selection and use of specific products sold by Lincoln Electric is solely within the control of, and remains the sole responsibility of the customer. Many variables beyond the control of Lincoln Electric affect the results obtained in applying these types of fabrication methods and service requirements. Subject to Change — This information is accurate to the best of our knowledge at the time of printing. Please refer to www.lincolnelectric.com for any updated information.



The Lincoln Electric Company

22801 St. Clair Avenue · Cleveland, OH · 44117-1199 · U.S.A.